



EPR-110

USB - Hard Disk Reader for EverFocus Digitalrecorder

WARNING

TO REDUCE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.
DO NOT REMOVE COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



WARNING: This equipment has been tested and found to comply with the limits for a Class "A" digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the users will be required to correct the interference at their own expense.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This Class A digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations.



ATTENTION! This is a class A product which may cause radio interference in a domestic environment; in this case, the user may be urged to take adequate measures.



Your EverFocus product is designed and manufactured with high quality materials and components which can be recycled and reused. This symbol means that electrical and electronic equipment should be disposed of separately from your household waste at their end-of-life.

Please dispose of this equipment at your local community waste collection / recycling centre. In the European Union, there are separate collection systems for used electrical and electronic products.

Please help us to conserve the environment we live in!



This product is RoHS compliant.

Notice:

The information in this manual was current when published. The manufacturer reserves the right to revise and improve its products. All specifications are therefore subject to change without notice.

Before installing and using this unit, please read this manual carefully. Please make sure to keep it handy for later reference.

Table of Contents

1. UNDERSTAND DVR READER	3
1.1 Package Content	3
1.2 Front Panel	3
1.3 Rear Panel.....	3
1.4 Minimum System Requirements.....	4
1.5 Specifications.....	4
2. SETUP DVR READER	5
2.1 Install DVR Reader software	5
2.2 Connect DVR Reader to PC.....	5
2.3 Insert HDD carrier to DVR Reader.....	6
2.4 Remove HDD carrier from DVR Reader.....	6
3. USING DVR READER SOFTWARE	7
3.1 Start DVR Reader Software	7
3.2 Understand User Interfaces	7
3.3 Basic Operations.....	8
3.3.1 Open DVR HDD/File.....	8
3.3.2 Playback Controls.....	9
3.3.3 Set Playback Channel.....	9
3.3.4 Select Display Mode	10
3.4 Search Video	10
3.4.1 Search by Date/Time	10
3.4.2 Search by Video Slide Bar	10
3.5 Snapshot and Archive	11
3.5.1 Archive Video from Video Window.....	11
3.5.2 Archive Video from Menu.....	13
3.5.3 Snapshot Image.....	13
3.6 View.....	13
3.7 Audio.....	14
3.8 Help	14
3.9 Exit	15


1. Understand DVR Reader

1.1 Package Content



The package includes DVR Reader, power adapter, power cord, USB2.0 cable, and keys.
Note: Hard disk tray is not included.

1.2 Front Panel



Note: Hard disk tray is not included.

1.3 Rear Panel



1.4 Minimum System Requirements

CPU	Intel® Pentium® 4, 3GHz processor or faster
Memory	512MB RAM
HDD	100MB hard disk space; additional disk space for video capture
USB	USB 2.0 port
Peripherals	Windows-compatible display with at least 1024x768 resolution Windows-compatible mouse or pointing device Windows-compatible sound card Windows-compatible CD-ROM drive
OS	Microsoft® Windows® 2000/XP™/7

1.5 Specifications

Supported Products

DVR Models	4/6/9/16 channel EverFocus DVR with removable 3.5" SATA HDD
------------	---

Front Panel

Lights	Two LED's to indicate power and hard disk activity
Lock	HDD tray lock

Rear Panel

Power switch	Power ON/OFF
Interface Connector	USB Type B connector
Power Connector	6 pin 5V/12V DC

Software Functions

Operations	1/4/9/16 multi-channel playback Playback forward/backward at 0.1~16x speed Audio playback for 1~60FPS recordings (MPEG4 4CH/8CH/16CH will not support audio function) Pause Step forward/backward Jump to beginning or end of a segment
Search	Search video by segment list, date/time and alarm list Slide bar to move video pointer Display current video date/time
Archive	Save still image to BMP or JPEG file Print still image Save video to Motion JPEG AVI file up to 4GB Save disk raw data into proprietary file Save meta-data to text or binary file *: Length limitation depends on various PC hardware, disk and OS configurations.

Power

Power	DC 5/12V vial external Power supply 110/230 VAC
-------	---

Operational Environment

Temperature	0 °C ~ 50°C (32 °F ~ 122°F)
-------------	-----------------------------

Dimensions & Weight

Dimensions (W/H/D)	155 mm × 47mm × 277mm (6.1in × 1.8in × 10.9in)
Weight	1.35 kg (3.0 lbs)


2. Setup DVR Reader

Note: Please carefully follow these instructions to insert or remove the HDD carrier to avoid damages to the DVR Reader or hard disk.

2.1 Install DVR Reader software

Please note that DVR Reader only supports Windows 2000/XP.


1. Turn on your PC
2. Insert DVR Reader CD-ROM
3. Run [DvrHddReader]:\setup.exe if the program does not automatically run




4. Click "Next" and follow the instructions to install DVR Reader software

2.2 Connect DVR Reader to PC


Step 1: Connect USB2.0 cable to DVR Reader and your PC



Step 2: Connect power adapter's cable to DVR Reader



Step 3: Connect power cord to power adapter



Step 4: Make sure the power switch is at OFF position

Step 5: Connect power cord to power surge

2.3 Insert HDD carrier to DVR Reader

WARNING! Make sure your HDD carrier is compatible with this DVR Reader. Inserting a wrong HDD carrier to DVR Reader will seriously damage the disk and the device.

1. Take out HDD carrier from DVR (Please refer to DVR user's manual)
2. Insert HDD carrier to DVR Reader and firmly push to the end
3. Lock HDD carrier
4. Turn on DVR Reader from power switch
5. Wait until the Remove/Eject icon shows up in System Tray



2.4 Remove HDD carrier from DVR Reader

1. Exit from DVR Reader application
2. Click on Remove/Eject icon in System Tray to stop the USB Mass Storage Device
3. Turn off the power
4. Unlock the HDD carrier lock
5. Remove HDD carrier from DVR Reader

3. Using DVR Reader Software

3.1 Start DVR Reader Software

Start DVR HD Reader software from desktop shortcut or from Start Menu *Start -> Program Files -> EverFocus HD Reader > EverFocus HD Reader*


3.2 Understand User Interfaces




3.3 Basic Operations

3.3.1 Open DVR HDD/File

1. Press "Menu" button and select "File", then "Load Drive". The PC will automatically detect all the DVR models available. Choose the proper DVR model to be viewed. Or, select "Open File" to load a disk image file (*.edr). Note that HDD/File Menu only shows the HDD's, which are recognized by DVR Reader software.




2. Please wait while DVR Reader is reading disk information. "Status Bar" shows the progress of reading disk process.
3. To load a disk image file (*.edr / *.avr), select "Open File") and browse file location.



3.3.2 Playback Controls


1. Click on *Playback Control Buttons* to Playback, Pause, reverse play, forward/reverse single step, fast forward/rewind and increase/decrease playback speed.



Note: Playback speed range is 0.1~16x and they are approximate speeds.

3.3.3 Set Playback Channel

1. Right click on *Video Window* where playback channel is to be set.
2. In *Function Menu*, click on *Set Channel* to choose desired playback channel.



Note: One channel can only be shown in one window. If two windows are set to playback the same channel, only the last one set will show video correctly.

3.3.4 Select Display Mode

1. Right click on *Video Window* to bring up *Function Menu*.
2. Click on *Display Mode* and choose desired display mode.



3.4 Search Video

3.4.1 Search by Date/Time

1. Set desired Date/Time on *Date/Time search drop-down box*. Click on the value to be adjusted first, then click
2. Click on GO button



3.4.2 Search by Video Slide Bar

1. Grab *Video Slide Bar* cursor to move to desired position.



2. Click  to magnify the time frame. Click  to reduce the time frame. Event types are represented by different colors. Please refer to the following chart for the meaning of events.

Color	Event Type
Gray	No event
Blue	Video Loss
Orange	Motion
Red	Alarm
Yellow	Other event

Note: When searching a video, if file size of the disk is large, the searching action will take time and has no response, nor any notification will be given.

3.5 Snapshot and Archive


3.5.1 Archive Video from Video Window

DVR Reader can archive video into AVI file or disk image. However, archive functions are not designed to save long time video. Archive to AVI file should always be limited to the minimum time range. Archive AVI file over 4GB is not supported.

- To set archive in/out points, click on *Archive In* button or *Archive Out* button when video playback at the point you wish to set.
 Note: for *Disk Image (.edr)* format, the actual *Archive In* time will be equal or earlier than specified time, and *Archive Out* time will be equal or later.



- Right click on *Video Window* to bring up *Function Menu*.
- Click on *Archive* to bring up *Save As* dialog box.
- Type in file name.
- Choose file type.




Type	Video	Data	
Motion JPEG Full Size (.avi)	√	*	Stretched and recompressed single channel video. Slow.
Disk Image (.avr)	√	√	Complete multi-channel archive. Fast. Can only be read by DVR Reader software
Data only - Text (.txt)		√	Data saved in text mode (reserved)

*Optional to save to a separate file

Table 3.1 Archive Type Comparison

(Please refer to **Appendix A** for detail Recommended Download (Free Software to play the enlarged avi video))

6. Check "Full Size" checkbox if full size video is desired.



Best view with 720x240 screen mode

7. Check "Capture Data" and choose *Text* or *Binary* if data capture is desired.
8. *Select Archiving Encoder*.
9. Text Overlay: select the color of Date/Time and Channel that will be shown on the archived video.
10. Check "Add Text" if you wish to add text, you can select the text color as well.
11. Select "*Interlaced*" for the text interlaced.
12. Click "Save" to start archiving. *Archive Encoder Selection* dialog box will show up. Please choose a video compressor available for your computer.

3.5.2 Archive Video from Menu

1. Click on the desired channel first.
2. Press "Menu" button and select "Tool".
3. Click on "Archive" and browse the destination folder where the image will be archived to.
4. Type in file name.
5. Choose file type: .avi , .avr or .txt.

Note: During Archive process, do not press "Cancel" button, as it may cause crash to the program.

3.5.3 Snapshot Image

3 methods are available to snapshot an image:

- 1.1 Click on the desired channel first.
- 1.2 Right click on *Video Window* to bring up *Function Menu*.
- 1.3 Click on *Snapshot* and browse the destination folder where the snapshot image will be saved to.
- 2.1 Click on the desired channel first
- 2.2 Press "Menu" button and select "Tool".
- 2.3 Click on "Snapshot" and browse the destination folder where the snapshot image will be saved to.

- 3.1 Click on the desired channel first.




- 3.2 Click on "Snapshot" button.

- 3.3 Browse the destination folder where the snapshot image will be saved to.


3.6 View

1. Press "Menu" button and select "View", then "Overlay". Select the item to be displayed from camera title, time and meta data. Click on the item to switch between show and hide mode.




3.7 Audio

Press "Menu" button and select "Tools", then "Audio". Click on "ON/OFF" to switch between audio on and audio off mode. Click on the channel number for the camera to be set.



3.8 Help

If you need to get any assistance, press "Menu" button and select "Help", then "Contact Us" to get help information.



3.9 Exit

To exit from EPR110, press "Menu" button and select "Exit". Or, press the "X" button located beside "Menu" button.



OR



EverFocus Electronics Corp.

Corporate Headquarter:

12F, No.79, Sec. 1 Shin-Tai Wu Road,
Hsi-Chih, Taipei 22101, Taiwan
TEL: +886-2-2698-2334
FAX: +886-2-2698-2380
www.everfocus.com.tw
marketing@everfocus.com.tw

U.S.A - California Office:

1801 Highland Avenue, Unit A,
Duarte, CA 91010, USA
TEL: +1-626-844-8888
FAX: +1-626-844-8838
www.everfocus.com
sales@everfocus.com

U.S.A - New York Office:

415 Oser Avenue, Unit S,
Happauge, NY 11788, USA
TEL: +1-631-436-5070
FAX: +1-631-436-5027
www.everfocus.com
sales@everfocus.com

Europe - Germany Office:

Albert-Einstein-Strasse 1,
D-46446 Emmerich, Germany
TEL: +49-2822-93940
FAX: +49-2822-939495
www.everfocus.de
info@everfocus.de

Europe - UK Office:

Unit 12, Spitfire Business Park, Hawker Road,
Croydon Surrey, CR0 4WD, UK
Tel: +44-20-8649-9757
Fax: +44-20-8649-9907
www.everfocusuk.co.uk
basil@everfocusuk.co.uk

China – Beijing Office:

Room 609, Technology Trade Building,
Shangdi Information Industry Base,
Haidian District, Beijing 100085, China
TEL: +86-10-6297-3336-39
FAX: +86-10-6297-1423
www.everfocus.com.cn
marketing@everfocus.com.cn

China – Shenzhen Office:

4F, No. 2, D4 Building, Wan Yelong Industrial Park,
Tangtou Road, Shiyan, Baoan,
Shenzhen, Guangdong 518101, China
TEL: +86-755-2765-1313
FAX: +86-755-2765-0337
www.everfocus.com.cn
marketing@everfocus.com.cn

Japan Office:

5F, Kinshicho City Building,
2-13-4 Koto-Bashi, Sumida-Ku,
Tokyo, 130-0022 Japan
TEL: +81-3-5625-8188
FAX: +81-3-5625-8189
www.everfocus.co.jp
info@everfocus.co.jp

India Office:

Suite 803, Housefin Bhavan, C-21,
Bandra Kurla Complex, Bandra (East),
Mumbai 400051, India
TEL: +91-222-444-8791
FAX: +91-222-444-8790
www.everfocus.in
sales@everfocus.in

